



**INSTALLATION INSTRUCTIONS**  
**AR® POWER CONES™**  
Mfg. p/n 202000  
(See pkg. label for Dist. p/n)

**ATTENTION INSTALLER** (if other than owner):

Please forward this instruction sheet and the warranty card to the purchaser of this product. These instructions also contain valuable information necessary to the end user.

**INTRODUCTION:**

These instructions describe the procedure for properly installing KHROME WERKS® AR® (Anti-Reversion) POWER CONES<sup>®</sup>. AR® POWER CONES<sup>®</sup> will work best on large exhaust port engines with performance (high overlap) cams. Review instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

**NOTE:** A NOTE provides key information to make procedures easier or clearer.

**CAUTION:** A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle or accessories.

**WARNING:** A WARNING indicates special procedures that must be followed to avoid injury or death to a motorcycle operator or person inspecting or repairing the motorcycle.

**TOOLS REQUIRED:**

- 1 . 9/16+combination wrench
- 1 . ½+combination wrench
- 1 . flat-bladed screwdriver
- 1 . ½+socket w/extension
- 1 . ratchet

**PROCEDURE:**

1. Remove heat shields from exhaust pipes. Remove exhaust system as instructed in your owner's manual.
2. Before installing AR® POWER CONES<sup>®</sup>, inspect exhaust gaskets to be sure they are in place, not distorted, and properly seated; replace if necessary.
3. Insert AR® POWER CONES<sup>®</sup> into header of exhaust pipe so that flange on cone seats on end of header, and reinstall exhaust system.

**KHROME WERKS®**  
67 Fifth St. N.E. • Pine Island, MN 55963