

# #H3716 MX Style Rear Fender kit

\*This kit is not compatible with strut cover. And required relocation of OEM turn signals and taillight.

(1) Rear Fender	1	(5) Spacer for Grommet	1	(9) Spring Washer M8	2
(2) Loop Frame	1	(6) Duracon Washer	1	(10) Hex Nut M8	2
(3) Seat Nut	2	(7) Hex Bolt M8 x 50	2	(11) Button Head Bolt 1/4-20 x 1/2	1
(4) Grommet	1	(8) Flat Washer M8	2	(12) Flat Washer M6 x16 - 1.0	1

**!** Before installation, thoroughly familiarize yourself with the instructions and illustrations. After installation, make sure all components fit and function correctly before use.

1. Remove OEM seat, turn signals and taillight wiring.
2. Remove fender strut covers, rear fender.
3. Refer to FigureA, install (4) Grommet and (5) Spacer on (1) Fender.
4. Refer to FigureB, install (3) Seat Nut using OEM seat clip on (1) Fender.
5. Refer to FigureC, install (1) Fender and (2) Loop Frame using hardware (7)-(10) temporary. \*but fasten OEM bolt and nut on front side of fender firmly in advance.
6. Refer to FigureD or E, fix seat, (1) Fender and (2) Loop Frame.
7. Fasten hardware (7)-(10) firmly.
8. Check all hardware are tightened surely.

\*connect wiring of turn signals and taillight after process5 before installing seat.

\*check and fasten every hardware regularly.

