



INSTALLATION INSTRUCTIONS
SISSY BAR SIDE STRAPS
For 1997-2008 FLHR ROAD KING®

Mfg. p/n 263715
(See pkg. label for Dist. p/n)

ATTENTION INSTALLER (if other than owner):

Please forward this instruction sheet and the warranty card to the purchaser of this product. These instructions also contain valuable information necessary to the end user.

INTRODUCTION:

These instructions describe the procedure for properly installing KHRÔME WERKS® Sissy Bar Side Straps for 1997-2008 Harley-Davidson Road King®. Review instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle or accessories.

WARNING: A WARNING indicates special procedures that must be followed to avoid injury or death to a motorcycle operator or person inspecting or repairing the motorcycle.

TOOLS REQUIRED:

- 1 . ¾+socket
- 1 . Socket wrench
- 1 . #4 Phillips screwdriver
- 1 . Torque wrench
- 1 . #40W Torx wrench
- 1 . 7/16+Combination wrench

CAUTION: Buildup of chrome plating on fasteners may cause seizing or binding during installation. Use anti-seize lubricant on the ¼ %20 button head screws to prevent this.

PROCEDURE:

1. Remove saddlebags.

NOTE: It will be easier to completely install Khrome Werks® side straps on one side of the bike, then repeat installation for the other side.

2. Loosen upper shock mounting bolt and back out far enough to allow side strap to fit between shock and fender support. Do not disconnect air lines on shocks.

3. Remove top rear Torx screw from Saddlebag Support Bracket. Discard Torx screw.

4. **NOTE:** This step is only used on right side to install air fitting relocation bracket. Remove Phillips screw on fender support and loosen front saddlebag bracket screw to allow fender support to pivot up enough to remove two Torx screws holding air fitting bracket to frame. Install supplied air fitting bracket using Torx screws removed, making sure to install with markings out. Remove and replace in same position air fittings from old bracket to new. Tighten Torx screws. Pivot fender support back into position and install Phillips screw removed previously. Tighten Phillips screw and front saddlebag bracket screw.

5. Install front of Khrome Werks® Side Strap around shock bolt and pivot down to position rear of Side Strap over screw hole removed in Step 3. Insert 5/16+18 screw and flat washer supplied through rear of side strap, 1.09+spacer, saddlebag support bracket and fender. Do not tighten hardware until sissy bar upright in installed (see Step 7).

6. Repeat steps 2, 3, and 5 for other side.

7. Install upright using button head screws supplied. Torque shock mounting bolts to factory manual specs. Tighten all other hardware now.

8. Install saddlebags removed in step 1.

USE AND CARE: Wash your accessories with the same care you use when washing your motorcycle. Use mild soap and water. DO NOT use abrasive chemicals or cleaners, or high pressure washers.

Suggested Khrome Werks® Uprights

- 263600 8.75+Lowboy Upright
- 263601 8.75+Mini Lowboy Upright
- 264170 8.75+Ultra Mini Lowboy Upright
- 263611 8.75+Round Upright
- 264190 8.75+Bantam Upright
- 264195 8.75+Rail Upright

KHRÔME WERKS®
67 Fifth St. N.E. • Pine Island, MN 55963