



## INSTALLATION INSTRUCTIONS

### SISSY BARS for 1958-84 FLH

Mfg. p/n 263603A

(See pkg. label for Dist. p/n)

#### ATTENTION INSTALLER (if other than owner):

Please forward this instruction sheet and the warranty card to the purchaser of this product. These instructions also contain valuable information necessary to the end user.

#### INTRODUCTION:

These instructions describe the procedure for properly installing KHROME WERKS® Sissy Bars onto 1958-84 FLH models. Review instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

**NOTE:** A NOTE provides key information to make procedures easier or clearer.

**CAUTION:** A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle or accessories.

**WARNING:** A WARNING indicates special procedures that must be followed to avoid injury or death to a motorcycle operator or person inspecting or repairing the motorcycle.

#### TOOLS REQUIRED:

- 2 . ½" combination wrenches
- 1 . #4 Phillips screwdriver
- 1 . 5/32" socket wrench

**CAUTION:** Buildup of chrome plating on fasteners may cause seizing or binding during installation. Use anti-seize lubricant on the ¼" buttonhead screws to prevent this.

#### PROCEDURE:

1. Attach upright to side straps, using ¼" #20 screws provided. Tighten.
2. If motorcycle is equipped with saddlebags, remove saddlebags and then the bolts securing saddlebag supports to fender braces on both sides. Save hardware. Remove front two Phillips head screws and nuts securing fender to fender brace on both sides. Discard screws; save other hardware.
3. Using care not to scratch fender, slide complete Sissy Bar onto outside of fender braces. Apply 1-2 drops of Loctite® 242 (blue) to threads of provided longer screws. Install screws through side straps, fender braces and fender. Install OEM hardware onto screw on inside of fender. Tighten.
4. Reattach saddlebag supports, using OEM hardware previously removed. Tighten. Install saddlebags.

**WARNING:** Before operating motorcycle, check all hardware to be sure it is tight.

**USE AND CARE:** Wash your accessories with the same care you use when washing your motorcycle. Use mild soap and water. DO NOT use abrasive chemicals or cleaners, or high pressure washers.

#### REFERENCE KW P/N

263600	8.75 Lowboy Upright
263601	8.75 Mini Lowboy Upright
263611	8.75 Round Upright
264170	8.75 Ultra Mini Lowboy Upright
264190	8.75 Bantam Upright
264195	8.75 Rail Upright
263603A	Side Straps f/58-84 FLH

**KHROME WERKS®**  
67 Fifth St. N.E. • Pine Island, MN 55963