



INSTALLATION INSTRUCTIONS

SISSY BAR SIDE PLATES
For 1982-1994, 1999-00 FXR models

Mfg. p/n 263606D
(See pkg. label for Dist. p/n)

ATTENTION INSTALLER (if other than owner):

Please forward this instruction sheet and the warranty card to the purchaser of this product. These instructions also contain valuable information necessary to the end user.

INTRODUCTION:

These instructions describe the procedure for properly installing KHRÔME WERKS® Sissy Bar Side Plates onto 1982-94 and 1999-2000 H-D FXR models. Review instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle or accessories.

WARNING: A WARNING indicates special procedures that must be followed to avoid injury or death to a motorcycle operator or person inspecting or repairing the motorcycle.

TOOLS REQUIRED:

- 1 . 7/16+socket wrench
- 1 . 9/16+combination wrench
- 2 . 1/2+combination wrenches
- 1 . 5/32+socket wrench

NOTE: Khrôme Werks® Sissy Bar Side Plates fit with Khrôme Werks® or Harley-Davidson® 6.69+width sissy bar uprights.

Suggested Khrôme Werks® Uprights

264197	6.69+Rail
264193	6.69+Bantam Upright
263605	6.69+Mini Lowboy Upright
263604	6.69+Lowboy Upright
263613	6.69+Round Upright

PROCEDURE:

1. Remove reflectors on sides of rear fender. Clean fender thoroughly.
2. Support rear of motorcycle so that rear wheel is just off the ground. This will allow for easier access to fender mounting hardware.
3. Remove hardware securing fender to strut. Discard spacer plate located between fender and frame. Save all mounting hardware.

1982-86 MODELS:

4. Carefully slide side plate between fender and fender strut . Install OEM hardware.

1987 – 2000 MODELS:

4. Carefully slide side plate between fender and strut. Side plate is slotted at rear hole to allow installation without removing turn signal wire. Washer between fender and strut will have to be removed. This can be done using a tin shears. Loosen strut enough to gain access to washer. Using care not to damage fender, snip washer in two places and remove. Install OEM hardware. Supplied spacer goes in front position between fender and frame.
5. Repeat for other side.
6. Attach Sissy Bar Upright to side plates, using hardware supplied. Align Sissy Bar assembly and tighten all hardware securely.
7. Reflectors may now be installed to side plates in their original position.

USE AND CARE: Wash your accessories with the same care you use when washing your motorcycle. Use mild soap and water. DO NOT use abrasive chemicals or cleaners, or high pressure washers.

BILL OF MATERIALS

Item#	Mfg. p/n	Description	Qty.
	2636063	Side Plate, Left	1
	2636064	Side Plate, Right	1
	433428	Screw, buttonhead socket 1/4-28 x 3/4+	4
	438973	Spacer	2

KHRÔME WERKS®
67 Fifth St. N.E. • Pine Island, MN 55963