



RSD DUAL CABLE THROTTLE GRIPS

TRACKER

CHRONO

TRACTION



PRODUCT DESCRIPTION

RSD TRACKER GRIPS :1984-UP HD DUAL CABLE MODELS

0063-2019

RSD BRASS TRACKER GRIPS :1984-UP HD DUAL CABLE MODELS

0063-2030

RSD CHRONO GRIPS :1984-UP HD DUAL CABLE MODELS

0063-2036

RSD BRASS CHRONO GRIPS :1984-UP HD DUAL CABLE MODELS

0063-2041

RSD TRACTION GRIPS :1984-UP HD DUAL CABLE MODELS

0063-2067

RSD BRASS TRACTION GRIPS :1984-UP HD DUAL CABLE MODELS

0063-2069

For questions pertaining to the installation of this product, please contact the Performance Machine technical department at 1-800-479-4037. This product is manufactured in the USA by Performance Machine LLC.

RSD DUAL CABLE THROTTLE GRIP INSTALLATION

1. Turn your motorcycle off, place securely on a lift or side stand and disconnect the battery.
2. Remove the two T25 switch housing screws.



3. Loosen up the throttle and idle cables using two 3/8" wrenches. Make sure to split the upper and lower switch housing enough to clear the groove on the throttle grip then slide off the throttle grip.



4. Slide the RSD throttle grip onto the handle bar and insert the throttle and idle cable ends. Position the upper and lower switch housing on the handle bar. Tighten the 2 Torx T25 screws to factory torque specs. **MAKE SURE THE THROTTLE OPERATES SMOOTHLY LOCK TO LOCK.** If operation is not smooth loosen the master cylinder and throttle housing and reposition to allow for smooth function.





RSD CLUTCH GRIP INSTALLATION

1. Remove the two T25 switch housing screws. Split the upper and lower switch housings to allow access to the grip.



2. Use a long flat blade screw driver to break loose the adhesive between the grip and the handle bar, or cut the grip off carefully. Install the upper and lower switch housing back onto the handle bar and tighten the T25 torx screws to factory specs.



3. Slide on the new RSD clutch grip until the grip stops against the switch housing. Using a 1/8" transfer punch and hammer, mark the set screw locations through the threaded holes in the grip.

NOTE: On the RSD Tracker grips make sure the RSD logo is horizontal.



4. Remove the grip and using a 1/8" center drill, drill two small dimples into the bar. These dimples will insure the grip will not rotate after the set screws are installed.



5. Using high strength thread locker and the supplied 5/64" allen key, tighten the two set screws on the grip, make sure the grip is secure. RSD Chrono Grips are supplied with extra badge so pick your favorite style badge to compliment your bike, peel the adhesive backing, and adhere to the end of the grips in a horizontal position.

