





Hole Cover for the Swing Arm Leg



After removing the rear bow, a bracket remains on the left swing arm.






Use the enclosed T45 L-key to unscrew the retaining screw of the bracket.



The hole cover is attached with the same original Torx screw.



The result.